

--	--	--	--	--

$$\square\square\square\square\square\square * 1\square\square\square\square\square\square * 1\square\square\square * 1\square\square\square\square\square\square\square\square * 1$$

Intelligent Sensor Sprayer

—A sharp tool for sterilization—

Timing injection / Infrared induction / No touch more assured



Intelligent upgrade infrared sensing

Intelligent chip control induction,
rapid response, hand spray.



Intelligent timing injection

One button timing injection of alcohol,
more convenient to use.



Timing injection



More convenient

The amount of alcohol spray is just right every time.

Each spray amount is reasonable and appropriate,
energy saving and safety, and alcohol use longer.



The built-in battery is not limited by the site

It is suitable for company, hotel, front desk, toilet and other public areas



school



table



family



hotel



hospital



company



Portable portable alcohol sprayer

No need to fix, small and easy to carry
It can be moved at any time, suitable for all kinds of places



Simple and fashionable design

Clean and tidy simple design style,
meticulous workmanship, practical and durable, can
With the integration of the overall home environment,
make life more intimate and natural.



Hand / article induction spray disinfection

Light and compact, suitable for all kinds of environment



Scene display of alcohol sprayer

Experience disinfection in various scenes







Product details



Double working mode
one key switch

- (1) intelligent induction spraying
- (2) automatic continuous spray

Large capacity 120ml



Large battery 1200Ma

Large spray volume
Breathing sleep lamp
Anti rollover and anti leakage liquid
Food grade kettle

.....



Product parameters



Product name

Intelligent sensor sprayer

Battery capacity

1200MA

frequency

110 ± 3 KiloHertz

Product size

75MM*65MM*100MM

Product input

DC 5V / 1A

Product capacity

120ML

Available in black and white

Black and white are available in two different colors



Supporting list

Smart sensor sprayer: 1 miniature USB cables: 1

Instruction manual: 1 absorbent cotton stick: 1





[instructions][instructions]

1. Take out the equipment and remove the bottom shell.
2. Rotate the bottle anticlockwise and take out the bottle and cotton swab. Then pour 75% alcohol or other liquid.
3. Put the cotton swab back and tighten the bottle, cover the bottom shell, and wait for 30 seconds.
4. Press and hold on / off button to start the machine (blue light is always on), and the product will enter the intelligent sensor spraying mode. Place your hand or object in the infrared sensor hole on the top of the device 0-15 cm, and the device starts spraying the hand or object in a short time.
5. In the intelligent sensing mode, press the on / off button (red, blue and yellow lights flash alternately) to switch to continuous spraying mode. Automatic spraying for 15 seconds every 3 minutes. In the continuous spraying mode, press the switch button again (the blue light is on for a long time) to enter the intelligent sensing mode. The working mode can be changed by the on / off button.
6. Press and hold the on / off button to close. Continuous spray operation mode is automatic shutdown for more than 6 hours.



[charging operation]

1. Connect the micro USB interface of the USB power cable to the micro USB interface of the product.
2. Connect the other end of the USB power cable with the 5V / 1A power adapter, and then connect the power adapter and plug it into the power socket.
3. When the product starts charging, the red light will flash, and the battery will be full of red light after 3 hours.
4. When starting up, if the yellow light of the product is on, it indicates that the battery is too low and needs to be charged.



[note]

1. This product does not provide disinfectant, please buy it yourself. 75% alcohol is recommended.
2. product is nano micropore spray. Do not pour oily liquid to avoid blockage.
3. Do not smoke or ignite near the equipment to avoid fire.
4. Prevent children from playing to avoid accidents.



1. 注意

1. 本产品不提供消毒剂，请自行购买。75%酒精是推荐的。

2. 本产品是纳米微孔喷雾。请勿倒入油性液体，以免堵塞。

3. 请勿吸烟或点火，以免发生火灾。

4. 防止儿童玩耍，以免发生事故。

4. 請提供詳細的報價單

2. 請提供詳細的報價單

1. Western Union / T / PayPal 付款

2. 30 天內付款，70 天內付款

3. 請提供詳細的報價單

3. 請提供

請提供詳細的報價單/請提供詳細的報價單/請提供詳細的報價單

請提供 TNT / FedEx / DHL / UPS / EMS 的詳細報價單

請提供 1-3 天的報價單

請提供 5-7 天的報價單

請提供 OEM 7-10 天的報價單

4. 請提供

1. Warranty 12 個月

2. 請提供詳細的報價單

3. 請提供詳細的報價單

請提供

Q 請提供詳細的報價單

A 請提供詳細的報價單 37 天內付款

Q 請提供詳細的報價單

A 請提供詳細的報價單 24 天內付款

Q 請提供詳細的報價單

A 請提供 EXW / FOB / CIF 的詳細報價單

Q 請提供詳細的報價單

A 請提供詳細的報價單 2 天內付款 OEM / OEM 請提供詳細的報價單