

Descripción de productos

dispensador de desinfectante proveedor de alcohol en aerosol:2020 nuevo diseño
Mini dispensador de aerosol de alcohol automático sin contacto Sensor infrarrojo
humidificador desinfectante de manos sin contacto,

Característica especial:

Modos de trabajo duales: modo de pulverización con sensor inteligente + modo de pulverización continuo automático, batería de 1200 mAh, luz de suspensión

Tipo de gel líquido: Diseño innovador de tipo spray de alcohol, sin enjuague y conveniente.

Operación simple: Fácil y conveniente verter el alcohol y el agua en el interior a través de la boca de la botella.

Capacidad: El tanque de agua de 120 ml tiene certificado FDA.

Automático y sin contacto: Sensor de infrarrojos sin contacto **humidificador desinfectante de manos fabricante**, seguro y saludable porque mantiene baja la propagación de gérmenes.

Aplicación amplia: Adecuado para uso diario y uso profesional, perfecto para el hogar, HOTEL, villa, APARTAMENTO, EDIFICIO DE OFICINAS, HOSPITAL, escuela, centro comercial, instalaciones deportivas, instalaciones de ocio, supermercado, BODEGA, TALLER, parque, granja, patio u otros lugares públicos.

Nota: para líquidos finos como alcohol, agua, etc.

Lista de paquetes:

Peso neto: 180g, paquete: 215g

Tamaño del producto: 75 * 65 * 100 mm

Tamaño del paquete del producto: 80 * 70 * 105 mm

Tamaño del cartón: 535 * 360 * 330 mm / 100PS / 22 KG

Accesorios: Host * 1, cable de carga * 1, hisopo de algodón * 1, manual de usuario * 1

Intelligent Sensor Sprayer

—A sharp tool for sterilization—

Timing injection / Infrared induction / No touch more assured



Intelligent upgrade infrared sensing

Intelligent chip control induction,
rapid response, hand spray.



Intelligent timing injection

One button timing injection of alcohol,
more convenient to use.



Timing injection



More convenient

The amount of alcohol spray is just right every time.

Each spray amount is reasonable and appropriate,
energy saving and safety, and alcohol use longer.



The built-in battery is not limited by the site

It is suitable for company, hotel, front desk, toilet and other public areas



school



table



family



hotel



hospital



company



Portable portable alcohol sprayer

No need to fix, small and easy to carry
It can be moved at any time, suitable for all kinds of places



Simple and fashionable design

Clean and tidy simple design style,
meticulous workmanship, practical and durable, can
With the integration of the overall home environment,
make life more intimate and natural.



Hand / article induction spray disinfection

Light and compact, suitable for all kinds of environment



Scene display of alcohol sprayer

Experience disinfection in various scenes







Product details



Double working mode
one key switch

- (1) intelligent induction spraying
- (2) automatic continuous spray

Large capacity 120ml



Large battery 1200Ma

Large spray volume
Breathing sleep lamp
Anti rollover and anti leakage liquid
Food grade kettle

.....



Product parameters



Product name

Intelligent sensor sprayer

Battery capacity

1200MA

frequency

110 ± 3 Kilohertz

Product size

75MM*65MM*100MM

Product input

DC 5V / 1A

Product capacity

120ML

Available in black and white

Black and white are available in two different colors



Supporting list

Smart sensor sprayer: 1 miniature USB cables: 1

Instruction manual: 1 absorbent cotton stick: 1





[instructions][instructions]

1. Take out the equipment and remove the bottom shell.
2. Rotate the bottle anticlockwise and take out the bottle and cotton swab. Then pour 75% alcohol or other liquid.
3. Put the cotton swab back and tighten the bottle, cover the bottom shell, and wait for 30 seconds.
4. Press and hold on / off button to start the machine (blue light is always on), and the product will enter the intelligent sensor spraying mode. Place your hand or object in the infrared sensor hole on the top of the device 0-15 cm, and the device starts spraying the hand or object in a short time.
5. In the intelligent sensing mode, press the on / off button (red, blue and yellow lights flash alternately) to switch to continuous spraying mode. Automatic spraying for 15 seconds every 3 minutes. In the continuous spraying mode, press the switch button again (the blue light is on for a long time) to enter the intelligent sensing mode. The working mode can be changed by the on / off button.
6. Press and hold the on / off button to close. Continuous spray operation mode is automatic shutdown for more than 6 hours.



[charging operation]

1. Connect the micro USB interface of the USB power cable to the micro USB interface of the product.
2. Connect the other end of the USB power cable with the 5V / 1A power adapter, and then connect the power adapter and plug it into the power socket.
3. When the product starts charging, the red light will flash, and the battery will be full of red light after 3 hours.
4. When starting up, if the yellow light of the product is on, it indicates that the battery is too low and needs to be charged.



[note]

1. This product does not provide disinfectant, please buy it yourself. 75% alcohol is recommended.
2. product is nano micropore spray. Do not pour oily liquid to avoid blockage.
3. Do not smoke or ignite near the equipment to avoid fire.
4. Prevent children from playing to avoid accidents.

Acerca de orden

1. cómo hacer un pedido

1. Díganos el modelo de producción y la cantidad u otra solicitud que necesite, luego haremos el PI por usted.
2. Después de confirmar el PI, organizaremos el pedido después de recibir su pago.

3. Después de terminar la mercancía, le enviaremos la mercancía y un número de seguimiento.
4. Realizaremos un seguimiento de sus productos hasta que los reciba.

2. pago disponible

1. Se aceptan Western Union, T / T y PayPal.
2. Depósito del 30% y 70% antes del envío.
3. Sin cobranza de pagos. Entregue los productos solo después del pago completo

3. embalaje y entrega

Embalaje: caja blanca / tubo de plástico / bandeja de espuma / hecho a medida

Envío: TNT / FedEx / DHL / UPS / EMS, precio más económico y reacción rápida.

Plazo de ejecución: 1-3 días laborables para la muestra

5-7 días laborables para pedidos a granel registrando varias cantidades

7-10 días hábiles para OEM después de recibir la confirmación y el pago de la muestra

4. servicio postventa

1. Garantía: 12 meses desde la fecha de envío
2. Cualquier elemento dañado, proporcione imágenes o video para su confirmación. Devuelva los productos defectuosos dentro de la garantía, los repararemos o enviaremos piezas de repuesto.
3. Seguimiento de las mercancías hasta que las reciba.

Preguntas más frecuentes

P: ¿Cómo puedo obtener el [rociador inteligente](#) muestras para comprobar su calidad?

R: El pedido de muestra está disponible, se puede enviar por Express, lo recibirá en 3-7 días.

P: ¿Qué puedo obtener el precio?

R: Por lo general, cotizamos dentro de las 24 horas posteriores a la recepción de su consulta. Si es muy urgente obtener el precio, infórmenos en su correo electrónico para que consideremos su consulta como una prioridad.

P: ¿Cuál es su plazo comercial de entrega?

A: Aceptamos puerto de destino EXW, FOB Shenzhen o CIF. Puede elegir el que sea más conveniente o rentable para usted.

P: ¿Qué pasa con el plazo de entrega para la producción en masa?

R: Honestamente, depende de la cantidad del pedido y de la temporada en que realice el pedido. El pedido de muestra es de 2 días. El pedido de OEM / OEM necesitará más tiempo.