













[www.o-leading.com](http://www.o-leading.com)

AXI □□□□□□□□

□□□











00 00 00	16 0 00 OEM pcb 00 0000
00 00 00	7-12 0



1. O-Leading 0 000 000 00000?

0000 0000 0000 000 00 000000.

1. 000000 ISO 9001 : 2008 0000 00 00000 000000.

00 00 0000 0000000 00000 00

3. 0000 0000 00 0 00. 0 : 0000 0000, X-ray 00, AOI (Automated Optical Inspector) 0 ICT (in-circuit testing).

4. 00 00 00 000000 00 00 00 00 0

5. 00 00 00 0 00

2. O-Leading 0 0000 00 00000 000000?

00 10 0 00 00 0000 (0 : 00, 00 00) 0000 0 0, 0 0 00 0 00 000000. 00 00 00000 00 00000 31 % 0000000. 00 0000 00 0000000. 0000 O-Leading 0 0000 0000000. 00 00 00, 00 00 0 0000 00000 0000 0000 00 0000. 0000 0000 0000 00000 00000.

0000 00000 00 000000 00000. 0000 0000000 0000 00 0 0000 0000 000000 00 0000 0 00000.

3. O-Leading 0 00 0000 0000 00 0 0 00000?

00 FR4, 0 TG 0 0 0000 00, Rogers, Arlon, Telfon, 00000 / 00 00 00, PI 0

4. PCB 0000 0000 00000 000000?

Gerber 274-X 00000 000000 00000 00 00 00000. 00 Cam350, CAD, Protel 99se, PADS, DXP 0 Eagle 00 0 0 0000

□.

5. □□ PCB□ □□□□ □□□□ □□□ □□□□□?

□□ □□ → □□ □□□ □□ → □□ □□ → □□ AOI → □□ □□ → □□□□ □□ □ □□ → □□□□ → PTH → □□ □□ → □□ □□□ □□ → □□ □□ → □□ □□ → □□ AOI → □□ □□□ → □□ □□ □□ → □□ □□□ → □□□□ → E / T → □□ □□.